


Spartan Model 100 Roll Aid Locking Pin Assembly Instructions



Install locking pin assembly located in tool box by inserting S-hook in holes in cross bar and pinch with pliers.



Spartan Tool, L.L.C.

1506 West Division
Mendota, IL 61342
800/435-3866

WWW.SPARTANTOOL.COM

Install locking pin assembly located in tool box by inserting S-hook in holes in cross bar and pinch with pliers.